

### Pilot Light & Pushbutton



XB2-EV16




XB2-EA121



XB2-BA42



XB2-BS542



XB2-BP42



XB2-BJ21



XB2-BD21

Description	Supply	Supply voltage	Color	Reference
Connected with light light-included	SA9s	direct connection	Green	XB2-EV163
		BA 9s light (1) not supply	Red	XB2-EV164
			Yellow	XB2-EV165
			Blue	XB2-EV166
Pushbutton spring return	N/O		Black	XB2-EA121
			Green	XB2-EA131
			N/C	
			Red	XB-EA142
Flush	N/O		N/C+N/O	
			Black	XB2-EA125
			Green	XB2-EA135
			Red	XB2-EA145
Turn to release red	N/C	30	Black	XB2-BA21
			Green	XB2-BA31
			Yellow	XB2-BA51
			Blue	XB2-BA61
Mushroom head 60mm	N/C	40	Red	XB2-EA142
			N/C	
			30	XB2-BS442
			40	XB2-BS542
2 positions stay put	N/O		60	XB2-BS642
			N/C	
			40	XB2-BS142
			N/O	
2 positions spring return from right to left	N/O		Black	XB2-BP21
			Green	XB2-BP31
			Yellow	XB2-BP51
			Blue	XB2-BP61
2 positions spring return from right to left	N/O+N/C		N/C	
			Red	XB2-BR42
			Standard	XB2-BD25
			Long	XB2-BJ25
3 positions stay put	N/O		Standard	XB2-BD41
			Long	XB2-BJ41
			N/O+N/C	
			Standard	XB2-BD45
3 positions stay put 2 spring return	N/O+N/C		Long	XB2-BJ45
			Standard	XB2-BD33
			Long	XB2-BJ33
			Standard	XB2-BD53
3 positions stay put 2 spring return	N/O+N/C		Long	XB2-BJ53