

Pilot Light & Pushbutton



XB2-ED21



XB2-EJ21



XB2-EG21



XB2-ES542



XB2-ES142



XB2-ER42

Description	Contact type	Operator	Reference	
2 position stay put	N/C	Standard handle	XB2-ED21	
		Long handle	XB2-EJ21	
	N/O+N/C	Standard handle	XB2-ED25	
		Long handle	XB2-EJ25	
2 position 1 spring return from right to left	N/O	Standard handle	XB2-ED41	
		Long handle	XB2-EJ41	
	N/O+N/C	Standard handle	XB2-ED45	
		Long handle	XB2-EJ45	
3 position stay put	N/O+N/O	Standard handle	XB2-ED33	
		Long handle	XB2-EJ33	
3 position 2 spring return to centre	N/O+N/O	Standard handle	XB2-ED53	
		Long handle	XB2-EJ53	
Description	Contact type	Key position removal	Reference	
2 positions stay put	N/O	Left	XB2-EG21	
		Left	XB2-EG25	
3 positions stay put	N/O+N/C	Center	XB2-EG33	
3 positions spring return	N/O+N/C	Center	XB2-EG73	
Description	Contact type	Dimeter (mm)	Color	Reference
Turn to release	N/C	30	Red	XB2-ES442
		40	Red	XB2-ES542
Description	Contact type	Color	Reference	
Mushroom head 60mm	N/O	Black	XB2-ER21	
		Green	XB2-ER31	
		Yellow	XB2-ER51	
		Blue	XB2-ER61	
		N/C		
	N/C	Red	XB2-ER42	