# **SENTAI**

# SENTAI CAN DESCRIPTION CAN DESCRIPTION

5SM1 2P 40A 30mA



5SM1 2P 63A 30mA



5SM1 4P 40A 30mA



5SM1 4P 63A 30mA

## **5SM1 series Earth Leakage Circuit Breaker**

### **APPLICATION**

Series 5SM1 earth leakage breakers apply to in AC circuit of frequency of 50Hz, rated voltage up to 415V, rated current up to 80A. It is mainly used as an indirect contact protection for human. It also can be used to prevent against the fire danger caused by earth fault current owing to equipment insulation damage. When the protective measures of the electric shock are out of work, the RCCB whose rated residual operating current less than 30mA can serve as the supplementary protection for indirect contact, but it can't be used as the sole direct contact protection.

### **PRODUCT FEATURES**

- 1. Series 5SM1 Leakage Breakers are the protector for pure electromagnetic residual current operation.
- 2. The operation function is unrelated to circuit voltage, but operation is reliable.
- 3. It can be reliably operated on the loss of phase or neutral.
- 4. The capacity of resisting electromagnetic interference is strong.

### **MAIN TECHNICAL DATA**

Type	Un (V)	Hz	lm I△m	Inc I△m	In A		I <sub>△no</sub>	The maximum of break-time (s)				
							mA	IAN	2I△N	5l△N	0.25A	500A
5SM1 2P	240	50, 60	500A (In≥ 50A 10In) (In> 50A)	6000A	6, 10, 16, 25, 32, 40, 50, 63, 80	30	15	0.2	0.1	-	0.04	0.04
						50	25	0.2	0.1	-	0.04	0.04
						75	40	0.2	0.1	-	0.04	0.04
						100	50	0.2	0.1	0.04	-	0.04
						300	150	0.2	0.1	0.04	0.04	0.04
						500	250	0.2	0.1	0.04	0.04	0.04
5SM1 4P	415	50, 60	500A (In≥ 50A 10In) (In> 50A)	6000A	6, 10, 16, 25, 32, 40, 50, 63, 80	30	15	0.2	0.1	-	0.04	0.04
						50	25	0.2	0.1	-	0.04	0.04
						75	40	0.2	0.1	-	0.04	0.04
						100	50	0.2	0.1	0.04	-	0.04
						300	150	0.2	0.1	0.04	0.04	0.04
						500	250	0.2	0.1	0.04	0.04	0.04

### **DIMENSION AND MOUNTING**

