

Relay Sockets



PF083A



PF083A-E



PF113A



PF113A-E



PF085A



PTF08A




PTF08A-E



PYF08A



PYF08A-E



PYF11A



PYF14A



PYF14A-E



PTF11A



PTF14A



PTF14A-E



PYF14.5A



PMF-14



P2CF-08



TP28X



JQX-38F Socket



PSF-08AE



PSF-14AE



TYPE 90.27



TYPE 94.74



TYPE 90.21



US-11



US-08



PT08A



PY-14A



PY-08A